

Using AmpTools to fit GlueX Data

Example Fit Goal: Extract a_2 from $\eta\pi^0$

- Use data sample from previous exercise
- The kinematics of $\eta\pi^0$ system (angular distributions) are given by the Z_ℓ^m functions discussed in the morning session
- Dynamical assumptions about how the amplitude depends on $M(\eta\pi^0)$
 - D-waves: a complex-valued Breit-Wigner with parameters consistent with the $a_2(1320)$
 - certain m-projections/reflectivities excluded based on tensor meson dominance (TMD) model
 - S-waves: fixed complex number in four coarse bins of $M(\eta\pi^0)$ (a piecewise complex function)
- Goal: extract the total efficiency corrected yield of $a_2(1320)$ (the coherent sum of all D-waves)

show plot

Required Code: AmpTools

- AmpTools: library that is distributed independently of GlueX code base
 - available through GitHub: github.com/mashephe/AmpTools
 - installed as external package in GlueX environment
 - (include version.xml lines here)
- The AmpTools library (not an executable) that provides a general interface for doing fits
 - fully functional example of how to use AmpTools is also provided in Tutorials/Dalitz
 - copyDalitz.py is provided to generate your own project based on the Dalitz tutorial (not needed for a typical GlueX user)
 - GlueX has a set of libraries and executables that rely on the core AmpTools package
 - halld_sim/src/libraries/AMPTOOLS_...
 - halld_sim/src/programs/AmplitudeAnalysis
 - Documentation concerning the theory of operation is available in the Git repository
 - AmpTools "knows" nothing about GlueX data format, physics, etc.
- Issue tracking system on GitHub is used -- report AmpTools problems there if they pertain to the core package and not the GlueX implementation

Required Code: Amplitudes

- Provide AmpTools with a method (code via a library) to convert the four-vectors of an event to a complex number
 - inherits from the Amplitude class in AmpTools which defines the interface for the object -- a template is provided to handle some necessary functions
 - see `Tutorials/Dalitz/DalitzLib/DalitzAmp/BreitWigner.h`
 - accepts arguments as an arbitrarily long list of strings (which will be specified in the config file)
- A collection of GlueX related amplitudes is here:
 - `halld_sim/src/libraries/AMPTOOLS_AMPS`
- Several optional features:
 - embed floating fit parameters (e.g., BreitWigner mass) into the calculation of the amplitude
 - perform a data reduction step to reduce four-vectors to "user variables," e.g., angles or Lorentz invariants, that are used to compute the amplitude
 - GPU acceleration of amplitude calculation -- requires additional code
 - *use of features increases complexity but can optimize performance – not a one-size-fits-all solution: ask for advice if you considering additional development to make fits run faster*
- The executable you write knows about the existence of the amplitudes through the static registration methods of the AmpToolsInterface
 - `AmpToolsInterface::registerAmplitude(BreitWigner());`
 - register before creating an instance of AmpToolsInterface to do your fit, generate MC, ...

Required Code: DataReader

- Provide AmpTools with a class that is able to turn a file on disk into a set of four-vectors
 - similar to Amplitude class: inherits from DataReader, uses a template for some key functions, and accepts arguments as a list of strings
 - see example in Tutorials/Dalitz
- Not usually analysis specific, but more specific to the file format
 - GlueX collection of data readers is here: `halld_sim/src/libraries/AMPTOOLS_DATAIO`
- Common GlueX formats for AmpTools input:
 - standard ROOT tree from ??? : `ROOTDataReader`
 - FSRoot format tree: `FSRootDataReader`
- Complex functionality can be added:
 - perform filtering or cuts during read into AmpTools
 - bootstrap: random sample with oversampling to evaluate uncertainties
- Not all components of a fit need to use the same data reader
- Like amplitudes, readers need to be registered prior to use:
 - `AmpToolsInterface::registerDataReader(DalitzDataReader());`

Configuration File: General Remarks

- See sample: Tutorials/Dalitz/run/dalitz3.cfg
- all lines begin with a keyword that informs the parser how to process the rest of the line
 - no continuation character: put it all on one line
 - ordering of the lines is not important
- useful keywords for organizing files:
 - include <file>
 - define <word> (defn1) (defn2) (defn3) ...
 - <word> must be isolated (spaces on each side) to be replaced
 - loop <word> <value1> (value2) (value3) ...
 - any line containing <word> will be repeated replacing <word> with <value1>, (value2), ...
 - multiple loops can be in a single line but they must be of the same length N -- then the line is repeated N times stepping through all loops in sync simultaneously
- some special syntax:
 - # as the first character denotes a comment
 - :: is treated like a space
 - [parname] -- use square brackets when the name of a parameter (instead of a numerical value) should be passed as an argument to an amplitude

Reactions, sums, and amplitudes

- Within a reaction, the intensity must be defined as a sum of coherent sums of amplitudes, where each amplitude can be a product of factors

$$\mathcal{I}(\mathbf{x}) = \sum_{\sigma} \left| \sum_{\alpha} s_{\sigma,\alpha} V_{\sigma,\alpha} A_{\sigma,\alpha}(\mathbf{x}) \right|^2$$

$$A_{\sigma,\alpha}(\mathbf{x}) = \prod_{\gamma=1}^{n_{\sigma,\alpha}} a_{\sigma,\alpha,\gamma}(\mathbf{x})$$

- Amplitudes can be scaled by a real number $s_{\sigma,\alpha}$ and have a complex production coefficient $V_{\sigma,\alpha}$
- This matches the general form for $\eta\pi$ production:

$$I(\Omega, \Phi) = 2\kappa \sum_k \left\{ (1 - P_\gamma) \left| \sum_{\ell,m} [\ell]_{m;k}^{(-)} \text{Re}[Z_\ell^m(\Omega, \Phi)] \right|^2 + (1 - P_\gamma) \left| \sum_{\ell,m} [\ell]_{m;k}^{(+)} \text{Im}[Z_\ell^m(\Omega, \Phi)] \right|^2 + \right. \\ \left. (1 + P_\gamma) \left| \sum_{\ell,m} [\ell]_{m;k}^{(+)} \text{Re}[Z_\ell^m(\Omega, \Phi)] \right|^2 + (1 + P_\gamma) \left| \sum_{\ell,m} [\ell]_{m;k}^{(-)} \text{Im}[Z_\ell^m(\Omega, \Phi)] \right|^2 \right\}.$$

- We absorb $\sqrt{1 \pm P_\gamma}$ into the definition of Z_ℓ^m and write $[\ell]_{m;k}^{(\pm)}$ as either a BreitWigner (for $\ell = 2$) or piecewise-defined function (for $\ell = 0$)
- Note that one $[\ell]_{m;k}^{(\pm)}$ appears in two sums: the production coefficients for each must be constrained to be the same and both terms must be included when computing anything physical from the result
- Multiple reactions are like doing multiple fits simultaneously: contributions to $\ln(L)$ add, parameters can be constrained across reactions

Example: Configuring Inputs

```
#####  
# GLOBAL VARIABLES  
#####
```

```
fit etapi0_SD_TMD_onePol
```

```
define polVal_00 0.3519  
define polAngle_00 0.0
```

```
define atwo 1.312 0.113
```

```
parameter pcwsBin_1ImPos 0.0 fixed  
parameter pcwsBin_1ImNeg 0.0 fixed
```

```
include starting_params.cfg
```

```
#####  
# SETUP INPUT, REACTIONS, SUMS  
#####
```

```
reaction EtaPi0_00 Beam Proton Eta Pi0
```

```
data EtaPi0_00 FSRootDataReader fsroot/tree_pi0eta__B4_M17_M7_DATA_sp17_pol0_SIGNAL_SKIM_A2.root ntFSGlueX_101_1 3
```

```
bkgnd EtaPi0_00 FSRootDataReader fsroot/tree_pi0eta__B4_M17_M7_DATA_sp17_pol0_SIDEBANDS_SKIM_A2.root ntFSGlueX_101_1 3  
fsroot/tree_pi0eta__B4_M17_M7_DATA_sp17_pol0_SIDEBANDS_SKIM_A2.root.weight ntFSGlueX_101_1_weight weight
```

```
accmc EtaPi0_00 FSRootDataReader fsroot/tree_pi0eta__B4_M17_M7_MC_sp17_pol0_SIGNAL_SKIM_A2.root ntFSGlueX_101_1 3  
fsroot/tree_pi0eta__B4_M17_M7_MC_sp17_pol0_SIGNAL_SKIM_A2.root.weight ntFSGlueX_101_1_weight weight
```

```
genmc EtaPi0_00 FSRootDataReader fsroot/tree_pi0eta__B4_M17_M7_MCGEN_sp17_pol0_GENERAL_SKIM_A2.root ntFSGlueX_101_1 3 MC
```

data: signal region events usually with unity weight, may contain backgrounds

bkgnd: (often) weighted sample that is statistically consistent with the background contribution to the signal region

accmc: accepted signal MC, consistent with the signal portion of the data sample

genmc: generated MC, used for denominator in efficiency calculations; in GlueX this should be tagged, generated MC

Example: Setting Up Amplitudes

```
sum EtaPi0_00 ReZ_1-P
sum EtaPi0_00 ImZ_1+P
sum EtaPi0_00 ReZ_1+P
sum EtaPi0_00 ImZ_1-P
```

$$I(\Omega, \Phi) = 2\kappa \sum_k \left\{ (1 - P_\gamma) \left| \sum_{\ell, m} [\ell]_{m; k}^{(-)} \text{Re}[Z_\ell^m(\Omega, \Phi)] \right|^2 + (1 - P_\gamma) \left| \sum_{\ell, m} [\ell]_{m; k}^{(+)} \text{Im}[Z_\ell^m(\Omega, \Phi)] \right|^2 + \right. \\ \left. (1 + P_\gamma) \left| \sum_{\ell, m} [\ell]_{m; k}^{(+)} \text{Re}[Z_\ell^m(\Omega, \Phi)] \right|^2 + (1 + P_\gamma) \left| \sum_{\ell, m} [\ell]_{m; k}^{(-)} \text{Im}[Z_\ell^m(\Omega, \Phi)] \right|^2 \right\}.$$

```
#####
# DEFINE AMPLITUDES
#####
```

S-wave amplitudes

```
amplitude EtaPi0_00::ReZ_1-P::S0- Zlm 0 0 +1 -1 polAngle_00 polVal_00
amplitude EtaPi0_00::ImZ_1+P::S0- Zlm 0 0 -1 +1 polAngle_00 polVal_00
amplitude EtaPi0_00::ReZ_1-P::S0- Piecewise 1.04 1.56 4 23 Neg ReIm [pcwsBin_0ReNeg] [pcwsBin_0ImNeg] [pcwsBin_1ReNeg]
[pcwsBin_1ImNeg] [pcwsBin_2ReNeg] [pcwsBin_2ImNeg] [pcwsBin_3ReNeg] [pcwsBin_3ImNeg]
amplitude EtaPi0_00::ImZ_1+P::S0- Piecewise 1.04 1.56 4 23 Neg ReIm [pcwsBin_0ReNeg] [pcwsBin_0ImNeg] [pcwsBin_1ReNeg]
[pcwsBin_1ImNeg] [pcwsBin_2ReNeg] [pcwsBin_2ImNeg] [pcwsBin_3ReNeg] [pcwsBin_3ImNeg]
```

```
amplitude EtaPi0_00::ImZ_1-P::S0+ Zlm 0 0 -1 -1 polAngle_00 polVal_00
amplitude EtaPi0_00::ReZ_1+P::S0+ Zlm 0 0 +1 +1 polAngle_00 polVal_00
amplitude EtaPi0_00::ImZ_1-P::S0+ Piecewise 1.04 1.56 4 23 Pos ReIm [pcwsBin_0RePos] [pcwsBin_0ImPos] [pcwsBin_1RePos]
[pcwsBin_1ImPos] [pcwsBin_2RePos] [pcwsBin_2ImPos] [pcwsBin_3RePos] [pcwsBin_3ImPos]
amplitude EtaPi0_00::ReZ_1+P::S0+ Piecewise 1.04 1.56 4 23 Pos ReIm [pcwsBin_0RePos] [pcwsBin_0ImPos] [pcwsBin_1RePos]
[pcwsBin_1ImPos] [pcwsBin_2RePos] [pcwsBin_2ImPos] [pcwsBin_3RePos] [pcwsBin_3ImPos]
```

D-wave amplitudes

```
amplitude EtaPi0_00::ImZ_1-P::a2_D0+ Zlm 2 0 -1 -1 polAngle_00 polVal_00
amplitude EtaPi0_00::ReZ_1+P::a2_D0+ Zlm 2 0 +1 +1 polAngle_00 polVal_00
amplitude EtaPi0_00::ImZ_1-P::a2_D0+ BreitWigner atwo 2 2 3
amplitude EtaPi0_00::ReZ_1+P::a2_D0+ BreitWigner atwo 2 2 3
```

amplitude factors with the same reaction::sum::amplitude are multiplied together



Example: Constraints and Initialization



Running the Fit



DEPARTMENT OF PHYSICS

INDIANA UNIVERSITY
College of Arts and Sciences
Bloomington

Viewing the Output



Extending to Multiple Polarization States



MPI Acceleration



DEPARTMENT OF PHYSICS

INDIANA UNIVERSITY
College of Arts and Sciences
Bloomington

GPU Acceleration



DEPARTMENT OF PHYSICS

INDIANA UNIVERSITY
College of Arts and Sciences
Bloomington